


MASTERBUILT®

Battery Box & PCB Kit


Portable Grill MB20040722, MB20040822, MB20040522, MB20040622




- Always remove plug from outlet before servicing your grill.
- Make sure your grill has fully cooled to avoid burns.
- Some components may have sharp edges. Use caution to avoid injury.




Remove battery box cover.




Remove 3 screws.




Disconnect and remove the battery box.



Disconnect 4 wires and carefully remove the PCB. There is adhesive tape on the backside of the PCB. Use caution.



Connect the new battery box and PCB.



Use the screws to secure the new battery box and PCB. Replace the cover.